



Note: The current shunt is selected by the value of the meter that is to be used.  
CURRENT SHUNT

Example: Meter full scale is 200mV,  
you want current to read as meter does.  
200mV divided by 20 amps = 0.01 ohms for shunt  
or 200mV divided by 200 amps = 0.001 ohms for shunt

Current shunts are rated in watts and mV per AMP/AMPS  
The best place to place the current shunt is in the positive side of the electronic load circuit.

[Http://www.EXEC-ENG.com](http://www.EXEC-ENG.com)

Title				CURRENT SHUNT USE			
Size	Number				Rev		
A					A		
Date	Mon Sep 20, 2004		Drawn by		DW		
Filename	CURRENT-SHUNT.SCH		Sheet		1 of 1		